

Adjustable Height Workcenters — ELECTRIC FRAME SETS

SECTION 1.2

QUICK REFERENCE CHART: ORDERING 2-LEG ELECTRIC WORKCENTERS

Step 1 Determine Shape & Size	Step 2 Select Worksurface	Step 3 Select Frame Set				Step 4 Select Control Switch		Step 5 Select Foot Kit	
24" Deep Rectangles	Block 3 mm	Essentia	Fundamentals EX	Sierra HX	Sierra HXL	Programmable	Standard	Styled	Flat
36 × 24	T3423-B3	ES3E30-48	FDEX30-48 or SEHX36 or SEHXL36			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	ES-FS24
42 × 24	T4023-B3	ES3E30-48	FDEX30-48 or SEHX42 or SEHXL42			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	ES-FS24
48 × 24	T4623-B3	ES3E30-48	FDEX30-48 or SEHX48 or SEHXL48			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	ES-FS24
54 × 24	T5223-B3	ES3E54-72	FDEX54-72 or SEHX54 or SEHXL54			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	ES-FS24
60 × 24	T5823-B3	ES3E54-72	FDEX54-72 or SEHX60 or SEHXL60			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	ES-FS24
66 × 24	T6423-B3	ES3E54-72	FDEX54-72 or SEHX66 or SEHXL66			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	ES-FS24
72 × 24	T7023-B3	ES3E54-72	FDEX54-72 or SEHX72 or SEHXL72			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	ES-FS24
30" Deep Rectangles									
36 × 30	T3429-B3	ES3E30-48	FDEX30-48 or SEHX36 or SEHXL36			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	ES-FS30
42 × 30	T4029-B3	ES3E30-48	FDEX30-48 or SEHX42 or SEHXL42			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	ES-FS30
48 × 30	T4629-B3	ES3E30-48	FDEX30-48 or SEHX48 or SEHXL48			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	ES-FS30
54 × 30	T5229-B3	ES3E54-72	FDEX54-72 or SEHX54 or SEHXL54			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	ES-FS30
60 × 30	T5829-B3	ES3E54-72	FDEX54-72 or SEHX60 or SEHXL60			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	ES-FS30
66 × 30	T6429-B3	ES3E54-72	FDEX54-72 or SEHX66 or SEHXL66			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	ES-FS30
72 × 30	T7029-B3	ES3E54-72	FDEX54-72 or SEHX72 or SEHXL72			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	ES-FS30
Small Equal Corner									
42 × 42 × 24	T404023-B3	ES3E30-48	FDEX30-48 or SEHX42 or SEHXL42-S			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	ES-FS30
48 × 48 × 24	T464623-B3	ES3E30-48	FDEX30-48 or SEHX48 or SEHXL48-S			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	ES-FS30
48 × 48 × 30	T464629-B3	ES3E30-48	FDEX30-48 or SEHX42-S or SEHXL42-S			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	ES-FS30
Large Offset Corner Left									
60 × 36 × 24	T583423-B3	ES3E54-72	FDEX54-72 or SEHX60 or SEHXL60			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK2430 or FFK2430	ES-FS2430
60 × 42 × 24	T584023-B3	ES3E54-72	FDEX54-72 or SEHX60 or SEHXL60			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK2430 or FFK2430	ES-FS2430
72 × 36 × 24	T703423-B3	ES3E54-72	FDEX54-72 or SEHX72 or SEHXL72			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK2430 or FFK2430	ES-FS2430
72 × 42 × 24	T704023-B3	ES3E54-72	FDEX54-72 or SEHX72 or SEHXL72			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK2430 or FFK2430	ES-FS2430
60 × 42 × 30	T584029-B3	ES3E54-72	FDEX54-72 or SEHX60 or SEHXL60			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	ES-FS30
72 × 42 × 30	T704029-B3	ES3E54-72	FDEX54-72 or SEHX72 or SEHXL72			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	ES-FS30
Large Offset Corner Right									
36 × 60 × 24	T345823-B3	ES3E54-72	FDEX54-72 or SEHX60 or SEHXL60			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK2430 or FFK2430	ES-FS2430
42 × 58 × 24	T405823-B3	ES3E54-72	FDEX54-72 or SEHX60 or SEHXL60			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK2430 or FFK2430	ES-FS2430
36 × 72 × 24	T347023-B3	ES3E54-72	FDEX54-72 or SEHX72 or SEHXL72			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK2430 or FFK2430	ES-FS2430
42 × 72 × 24	T407023-B3	ES3E54-72	FDEX54-72 or SEHX72 or SEHXL72			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK2430 or FFK2430	ES-FS2430
42 × 60 × 30	T405829-B3	ES3E54-72	FDEX54-72 or SEHX60 or SEHXL60			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	ES-FS30
42 × 72 × 30	T407029-B3	ES3E54-72	FDEX54-72 or SEHX72 or SEHXL72			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	ES-FS30
120 Degree Corner									
36 × 36 × 24	T343423T-B3	ES3E30-48	FDEX30-48 or SEHX42 or SEHXL42			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	ES-FS24
42 × 42 × 24	T404023T-B3	ES3E30-48	FDEX30-48 or SEHX48 or SEHXL48			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	ES-FS24
48 × 48 × 24	T464623T-B3	ES3E54-72	FDEX54-72 or SEHX54 or SEHXL54			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	ES-FS24
36 × 36 × 30	T343429T-B3	ES3E54-72	FDEX30-48 or SEHX42 or SEHXL42			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	ES-FS30
42 × 42 × 30	T404029T-B3	ES3E54-72	FDEX30-48 or SEHX48 or SEHXL48			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	ES-FS30
48 × 48 × 30	T464629T-B3	ES3E54-72	FDEX54-72 or SEHX54 or SEHXL54			PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	ES-FS30

QUICK REFERENCE CHART: ORDERING 3-LEG ELECTRIC WORKCENTERS

Step 1 Determine Shape & Size	Step 2 Select Worksurface	Step 3 Select Frame Set		Step 4 Select Control Switch		Step 5 Select Foot Kit		
Large Equal Corners	Block 3 mm	Essentia	Sierra HX	Sierra HXL	Programmable	Standard	Styled	Flat
60 × 60 × 24	T585823-B3	ES3E5472EOC	SEHX60EC or SEHXL60EC		PROSWITCH or STDSWITCH		SFK24 or FFK24	n/a or ES-FS24
66 × 66 × 24	T646423-B3	ES3E5472EOC	SEHX66EC or SEHXL66EC		PROSWITCH or STDSWITCH		SFK24 or FFK24	n/a or ES-FS24
72 × 72 × 24	T707023-B3	ES3E5472EOC	SEHX72EC or SEHXL72EC		PROSWITCH or STDSWITCH		SFK24 or FFK24	n/a or ES-FS24
60 × 60 × 30	T585829-B3	ES3E5472EOC	SEHX54EC or SEHXL54EC		PROSWITCH or STDSWITCH		SFK30 or FFK30	n/a or ES-FS30
66 × 66 × 30	T646429-B3	ES3E5472EOC	SEHX60EC or SEHXL60EC		PROSWITCH or STDSWITCH		SFK30 or FFK30	n/a or ES-FS30
72 × 72 × 30	T707029-B3	ES3E5472EOC	SEHX66EC or SEHXL66EC		PROSWITCH or STDSWITCH		SFK30 or FFK30	n/a or ES-FS30
Large Offset Corners, Left								
60 × 48 × 24	T584623-B3	ES3E5472-4248OC	SEHX6048OC or SEHXL6048OC		PROSWITCH or STDSWITCH		SFK24 or FFK24	n/a or ES-FS24
72 × 48 × 24	T704623-B3	ES3E5472-4248OC	SEHX7248OC or SEHXL7248OC		PROSWITCH or STDSWITCH		SFK24 or FFK24	n/a or ES-FS24
72 × 60 × 24	T705823-B3	ES3E5472EOC	SEHX7260OC or SEHXL7260OC		PROSWITCH or STDSWITCH		SFK24 or FFK24	n/a or ES-FS24
84 × 48 × 24	T824623-B3	ES3E7890-4248OC	SEHX8448OC or SEHXL8448OC		PROSWITCH or STDSWITCH		SFK24 or FFK24	n/a or ES-FS24
60 × 48 × 30	T584629-B3	ES3E5472-4248OC	SEHX5442OC or SEHXL5442OC		PROSWITCH or STDSWITCH		SFK30 or FFK30	n/a or ES-FS30
72 × 48 × 30	T704629-B3	ES3E5472-4248OC	SEHX6642OC or SEHXL6642OC		PROSWITCH or STDSWITCH		SFK30 or FFK30	n/a or ES-FS30
72 × 60 × 30	T705829-B3	ES3E5472EOC	SEHX6658OC or SEHXL6658OC		PROSWITCH or STDSWITCH		SFK30 or FFK30	n/a or ES-FS30
84 × 48 × 30	T824629-B3	ES3E7890-4248OC	SEHX7842OC or SEHXL7842OC		PROSWITCH or STDSWITCH		SFK30 or FFK30	n/a or ES-FS30
Large Offset Corners, Right								
48 × 60 × 24	T465823-B3	ES3E5472-4248OC	SEHX6048OC or SEHXL6048OC		PROSWITCH or STDSWITCH		SFK24 or FFK24	n/a or ES-FS24
48 × 72 × 24	T467023-B3	ES3E5472-4248OC	SEHX7248OC or SEHXL7248OC		PROSWITCH or STDSWITCH		SFK24 or FFK24	n/a or ES-FS24
60 × 72 × 24	T587023-B3	ES3E5472EOC	SEHX7260OC or SEHXL7260OC		PROSWITCH or STDSWITCH		SFK24 or FFK24	n/a or ES-FS24
48 × 84 × 24	T468223-B3	ES3E7890-4248OC	SEHX8448OC or SEHXL8448OC		PROSWITCH or STDSWITCH		SFK24 or FFK24	n/a or ES-FS24
48 × 60 × 30	T465829-B3	ES3E5472-4248OC	SEHX5442OC or SEHXL5442OC		PROSWITCH or STDSWITCH		SFK30 or FFK30	n/a or ES-FS30
48 × 72 × 30	T467029-B3	ES3E5472-4248OC	SEHX6642OC or SEHXL6642OC		PROSWITCH or STDSWITCH		SFK30 or FFK30	n/a or ES-FS30
60 × 72 × 30	T587029-B3	ES3E5472EOC	SEHX6658OC or SEHXL6658OC		PROSWITCH or STDSWITCH		SFK30 or FFK30	n/a or ES-FS30
48 × 84 × 30	T468229-B3	ES3E7890-4248OC	SEHX7842OC or SEHXL7842OC		PROSWITCH or STDSWITCH		SFK30 or FFK30	n/a or ES-FS30