

QUICK REFERENCE CHART: ORDERING 2-LEG ELECTRIC WORKCENTERS

Step 1 Determine Shape & Size	Step 2 Select Worksurface	Step 3 Select Frame Set		Step 4 Select Control Switch		Step 5 Select Foot Kit	
24" Deep Rectangles	Block 3 mm	Essentia	Sierra HX	Programmable	Standard	Styled	Flat
36 × 24	T3423-B3	ES3E30-48	SEHX30-48	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK24 or n/a	FFK24 or ES-FS24
42 × 24	T4023-B3	ES3E30-48	SEHX30-48	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK24 or n/a	FFK24 or ES-FS24
48 × 24	T4623-B3	ES3E30-48	SEHX30-48	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK24 or n/a	FFK24 or ES-FS24
54 × 24	T5223-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK24 or n/a	FFK24 or ES-FS24
60 × 24	T5823-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK24 or n/a	FFK24 or ES-FS24
66 × 24	T6423-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK24 or n/a	FFK24 or ES-FS24
72 × 24	T7023-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK24 or n/a	FFK24 or ES-FS24
30" Deep Rectangles							
36 × 30	T3429-B3	ES3E30-48	SEHX30-48	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK30 or n/a	FFK30 or ES-FS30
42 × 30	T4029-B3	ES3E30-48	SEHX30-48	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK30 or n/a	FFK30 or ES-FS30
48 × 30	T4629-B3	ES3E30-48	SEHX30-48	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK30 or n/a	FFK30 or ES-FS30
54 × 30	T5229-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK30 or n/a	FFK30 or ES-FS30
60 × 30	T5829-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK30 or n/a	FFK30 or ES-FS30
66 × 30	T6429-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK30 or n/a	FFK30 or ES-FS30
72 × 30	T7029-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK30 or n/a	FFK30 or ES-FS30
90 × 30	T8829-B3	ES3E78-90	SEHX78-90	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK30 or n/a	FFK30 or ES-FS30
Small Equal Corner							
42 × 42 × 24	T404023-B3	ES3E30-48	SEHX30-48	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK30 or n/a	FFK30 or ES-FS30
48 × 48 × 24	T464623-B3	ES3E30-48	SEHX30-48	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK30 or n/a	FFK30 or ES-FS30
48 × 48 × 30	T464629-B3	ES3E30-48	SEHX30-48	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK30 or n/a	FFK30 or ES-FS30
Large Offset Corner Left							
60 × 36 × 24	T583423-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK2430 or n/a	FFK2430 or ES-FS2430
60 × 42 × 24	T584023-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK2430 or n/a	FFK2430 or ES-FS2430
72 × 36 × 24	T703423-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK2430 or n/a	FFK2430 or ES-FS2430
72 × 42 × 24	T704023-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK2430 or n/a	FFK2430 or ES-FS2430
60 × 42 × 30	T584029-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK30 or n/a	FFK30 or ES-FS30
72 × 42 × 30	T704029-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK30 or n/a	FFK30 or ES-FS30
Large Offset Corner Right							
36 × 60 × 24	T345823-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK2430 or n/a	FFK2430 or ES-FS2430
42 × 58 × 24	T405823-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK2430 or n/a	FFK2430 or ES-FS2430
36 × 72 × 24	T347023-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK2430 or n/a	FFK2430 or ES-FS2430
42 × 72 × 24	T407023-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK2430 or n/a	FFK2430 or ES-FS2430
42 × 60 × 30	T405829-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK30 or n/a	FFK30 or ES-FS30
42 × 72 × 30	T407029-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK30 or n/a	FFK30 or ES-FS30
120 Degree Corner							
36 × 36 × 24	T343423T-B3	ES3E30-48	SEHX30-48	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK24 or n/a	FFK24 or ES-FS24
42 × 42 × 24	T404023T-B3	ES3E30-48	SEHX30-48	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK24 or n/a	FFK24 or ES-FS24
48 × 48 × 24	T464623T-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK24 or n/a	FFK24 or ES-FS24
36 × 36 × 30	T343429T-B3	ES3E54-72	SEHX30-48	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK30 or n/a	FFK30 or ES-FS30
42 × 42 × 30	T404029T-B3	ES3E54-72	SEHX30-48	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK30 or n/a	FFK30 or ES-FS30
48 × 48 × 30	T464629T-B3	ES3E54-72	SEHX54-72	PROSWITCH or ES-P-SWITCH	or STDSWITCH or ES-B-SWITCH	SFK30 or n/a	FFK30 or ES-FS30

QUICK REFERENCE CHART: ORDERING 3-LEG ELECTRIC WORKCENTERS

Step 1 Determine Shape & Size	Step 2 Select Worksurface	Step 3 Select Frame Set		Step 4 Select Control Switch		Step 5 Select Foot Kit	
Large Equal Corners	Block 3 mm	Essentia	Sierra HX	Programmable	Standard	Styled	Flat
60 × 60 × 24	T585823-B3	SEHX5472EOC	SEHX5472EOC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	n/a or ES-FS24
66 × 66 × 24	T646423-B3	ES3E5472EOC	SEHX5472EOC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	n/a or ES-FS24
72 × 72 × 24	T707023-B3	ES3E5472EOC	SEHX5472EOC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	n/a or ES-FS24
60 × 60 × 30	T585829-B3	ES3E5472EOC	SEHX5472EOC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	n/a or ES-FS30
66 × 66 × 30	T646429-B3	ES3E5472EOC	SEHX5472EOC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	n/a or ES-FS30
72 × 72 × 30	T707029-B3	ES3E5472EOC	SEHX5472EOC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	n/a or ES-FS30
Large Offset Corners, Left							
60 × 48 × 24	T584623-B3	SEHX5472-4248OC	SEHX5472-4248OC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	n/a or ES-FS24
72 × 48 × 24	T704623-B3	ES3E5472-4248OC	SEHX5472-4248OC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	n/a or ES-FS24
72 × 60 × 24	T705823-B3	ES3E5472EOC	SEHX5472EOC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	n/a or ES-FS24
84 × 48 × 24	T824623-B3	ES3E7890-4248OC	SEHX7890-4248OC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	n/a or ES-FS24
60 × 48 × 30	T584629-B3	ES3E5472-4248OC	SEHX5472-4248OC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	n/a or ES-FS30
72 × 48 × 30	T704629-B3	ES3E5472-4248OC	SEHX5472-4248OC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	n/a or ES-FS30
72 × 60 × 30	T705829-B3	ES3E5472EOC	SEHX5472EOC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	n/a or ES-FS30
84 × 48 × 30	T824629-B3	ES3E7890-4248OC	SEHX7890-4248OC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	n/a or ES-FS30
90 × 72 × 30	T887029-B3	ES3E7890-5472OC	SEHX7890-5472OC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	n/a or ES-FS30
Large Offset Corners, Right							
48 × 60 × 24	T465823-B3	SEHX5472-4248OC	SEHX5472-4248OC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	n/a or ES-FS24
48 × 72 × 24	T467023-B3	ES3E5472-4248OC	SEHX5472-4248OC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	n/a or ES-FS24
60 × 72 × 24	T587023-B3	ES3E5472EOC	SEHX5472EOC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	n/a or ES-FS24
48 × 84 × 24	T468223-B3	ES3E7890-4248OC	SEHX7890-4248OC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK24 or FFK24	n/a or ES-FS24
48 × 60 × 30	T465829-B3	ES3E5472-4248OC	SEHX5472-4248OC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	n/a or ES-FS30
48 × 72 × 30	T467029-B3	ES3E5472-4248OC	SEHX5472-4248OC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	n/a or ES-FS30
60 × 72 × 30	T587029-B3	ES3E5472EOC	SEHX5472EOC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	n/a or ES-FS30
48 × 84 × 30	T468229-B3	ES3E7890-4248OC	SEHX7890-4248OC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	n/a or ES-FS30
72 × 90 × 30	T708829-B3	ES3E7890-5472OC	SEHX7890-5472OC	PROSWITCH or STDSWITCH	ES-P-SWITCH or ES-B-SWITCH	SFK30 or FFK30	n/a or ES-FS30

QUICK REFERENCE CHART: ORDERING CASCADE WORKCENTERS

Step 1 Determine Shape & Size	Step 2 Select Worksurface	Step 3 Select Frame Set
24" Deep Rectangles	Block - 3 mm	Cascade Counter-Balance
48 × 24	T4623-B3	CC4824
54 × 24	T5223-B3	CC4824
60 × 24	T5823-B3	CC6024
66 × 24	T6423-B3	CC6024
72 × 24	T7023-B3	CC7224
30" Deep Rectangles		
48 × 30	T4629-B3	CC4830
54 × 30	T5229-B3	CC4830
60 × 30	T5829-B3	CC6030
66 × 30	T6429-B3	CC6030
72 × 30	T7029-B3	CC7230

QUICK REFERENCE CHART: ORDERING SIERRA HXL CRANK WORKCENTERS

Step 1 Determine Shape & Size	Step 2 Select Worksurface	Step 3 Select Frame Set	Step 4 Select Foot Kit	
24" Deep Rectangles	Block - 3 mm	HXL Crank	Styled	Flat
36 × 24	T3423-B3	SCFHXL36	SFK24	or FFK24
42 × 24	T4023-B3	SCFHXL42	SFK24	or FFK24
48 × 24	T4623-B3	SCFHXL48	SFK24	or FFK24
54 × 24	T5223-B3	SCFHXL54	SFK24	or FFK24
60 × 24	T5823-B3	SCFHXL60	SFK24	or FFK24
66 × 24	T6423-B3	SCFHXL66	SFK24	or FFK24
72 × 24	T7023-B3	SCFHXL72	SFK24	or FFK24
30" Deep Rectangles				
36 × 30	T3429-B3	SCFHXL36	SFK30-S	or FFK30-S
42 × 30	T4029-B3	SCFHXL42	SFK30-S	or FFK30-S
48 × 30	T4629-B3	SCFHXL48	SFK30-S	or FFK30-S
54 × 30	T5229-B3	SCFHXL54	SFK30-S	or FFK30-S
60 × 30	T5829-B3	SCFHXL60	SFK30-S	or FFK30-S
66 × 30	T6429-B3	SCFHXL66	SFK30-S	or FFK30-S
72 × 30	T7029-B3	SCFHXL72	SFK30-S	or FFK30-S
Small Equal Corner				
42 × 42 × 24	T404023-B3	SCTHXL42	SFK24	or FFK24
48 × 48 × 24	T464623-B3	SCTHXL48	SFK24	or FFK24
48 × 48 × 30	T464629-B3	SCTHXL42	SFK30	or FFK30
Large Offset Corner, Left				
60 × 36 × 24	T583423-B3	SCFHXL60	SFK2430	or FFK2430
60 × 42 × 24	T584023-B3	SCFHXL60	SFK2430	or FFK2430
72 × 36 × 24	T703423-B3	SCFHXL72	SFK2430	or FFK2430
72 × 42 × 24	T704023-B3	SCFHXL72	SFK2430	or FFK2430
60 × 42 × 30	T584029-B3	SCFHXL60	SFK30	or FFK30
72 × 42 × 30	T704029-B3	SCFHXL72	SFK30	or FFK30
Large Offset Corner, Right				
36 × 60 × 24	T345823-B3	SCFHXL60	SFK2430	or FFK2430
42 × 60 × 24	T405823-B3	SCFHXL60	SFK2430	or FFK2430
36 × 72 × 24	T347023-B3	SCFHXL72	SFK2430	or FFK2430
42 × 72 × 24	T407023-B3	SCFHXL72	SFK2430	or FFK2430
42 × 60 × 30	T405829-B3	SCFHXL60	SFK30	or FFK30
42 × 72 × 30	T407029-B3	SCFHXL72	SFK30	or FFK30
120 Degree Corner				
36 × 36 × 24	T343423T-B3	SCTHXL42	SFK24	or FFK24
42 × 42 × 24	T404023T-B3	SCTHXL48	SFK24	or FFK24
48 × 48 × 24	T464623T-B3	SCTHXL54	SFK24	or FFK24
36 × 36 × 30	T343429T-B3	SCTHXL42	SFK30	or FFK30
42 × 42 × 30	T404029T-B3	SCTHXL48	SFK30	or FFK30
48 × 48 × 30	T464629T-B3	SCTHXL54	SFK30	or FFK30